

Clean Remote – CRKC1 Instructions

Compatible with LG TVs with BED 1, 2, 3 and 4 functions

Important:

- Refer to your TV's owner's manual for setting the BED Number on your TV
- The CRKC1 remote control is preset for BED 2 code

Install 2 AAA batteries, see battery compartment for proper battery alignment.

How to change the BED Number code on the CRKC1 remote control:

The BED selector switch is located inside the battery compartment, at the bottom of the remote.

Note: Tilting the remote slightly will make it easier to access the switch.

Using a paperclip or similar device gently slide the switch to the TV's BED Number setting (BED 1, 2, 3 or 4). The remote will then transmit the selected BED Number code.

Replaces: LG 124-213-10, AKB73055503, AKB73075301 and 1919290191

